

Insulation monitor, DC-networks

Insulation monitoring of your DC networks



The ADL-111Q96 is used to supervise the insulation resistance between an isolated voltage distribution network and an earth/safety cable. The insulation monitor is applicable with DC networks for voltages of 24, 110 or 220 V DC. The ADL-111Q96 has a relay output with adjustable set point, and it can be configured to either NE (normally energised) or ND (normally de-energised).

ADL-111Q96 features

- ▶ Advanced insulation monitoring of 24, 110 and 220 V DC networks
- ▶ Detects all types of insulation faults – including double faults
- ▶ Configurable alarm with adjustable set point

